





Deal Drawing of the Structure and List of Parts

■ VR626*LVM / VR627*LVM - BASE ASSEMBLY











Deal Drawing of the Structure and List of Parts

■ VR626*LVM / VR627*LVM - Cover Assembly




Deal Drawing of the Structure and List of Parts

■ VR626*LVM / VR627*LVM - Charger.Battery




Deal Drawing of the Structure and List of Parts

■ VR626*LVM / VR627*LVM - Tank Assembly,Dust




Deal Drawing of the Structure and List of Parts

■ VR626*LVM / VR627*LVM - Remote Controller Assembly



Deal Drawing of the Structure and List of Parts

■ VR626*LVM / VR627*LVM - Accessory Assembly



EBM61201301