



■ VR62***LV - Base Assembly











■ VR62***LV - Cover Assembly






■ VR62***LV - Charger, Battery






■ VR62***LV - Tank Assembly, Dust






■ VR62***LV - Remote Controller Assembly



■ VR62***LV - Accessory Assembly





EBM61201301